




**W 1** WINDOW 1 DETAIL  
REQUIRED: 3 SETS




**W 2** WINDOW 2 DETAIL  
REQUIRED: 6 SETS



**W 4** WINDOW 4 DETAIL  
REQUIRED: 6 SETS



**W 5** WINDOW 4 DETAIL  
REQUIRED: 6 SETS



**W 3** WINDOW 3 DETAIL  
REQUIRED: 14 SETS

NOTE 1:

- REMOVE ALL WINDOW ELEMENTS, PAINT ALUMINUM FRAME WITH IVORY ACRYLIC PAINT, SMOOTHEN ALUMINUM FRAME/ ELEMENTS USING SAND PAPER BEFORE PAINTING
- REPLACE MISSING BLADES WITH SAME TYPE, INSTALL NEW ALUMINUM INSECT SCREEN AND ALUMINUM FRAMING CLIP(ANALOK)

NOTE 2:

- REINSTALL ALL WINDOW GRILLES
- REPAINT ALL WINDOW GRILLES; QDE PAINT
- QUICK DRYING ENAMEL